



REPAIR PROCEDURE INSTRUCTION SHEET Mohawk Fil-Stik

Mohawk's Fil-Stik is a semi hard putty stick used to fill nicks and scratches or open corner joints. Can be colored with Mohawk Touch Up Markers and / or protected with Mohawk Clear Lacquer



Clean the damaged area with a razor knife to remove any loose material. Select a color of Mohawk Fil-Stik that best matches the over all color.



Rub the Fil-Stik into the damaged area. Or, break off a small piece of Fil-Stik and press it in to the damaged area.



Using a plastic scraper or synthetic steel wool, level the Fil-Stik to the surrounding area. With a soft cloth, carefully wipe away excess.



If desired, this repair can be colored with a Mohawk Touch Up Marker or coated with Mohawk Clear Lacquer in the appropriate sheen.

Mohawk Finishing
Products